

## FORE & AFT MARINE

### FUEL SPILL DEVICES



## Splash-Stop for Fuel




Stop soiling your deck and polluting the water with diesel fuel by using a VETUS "Splash-Stop".

L x W x H = 9 15/16" x 4 3/4" x 9 1/8"

Patent NR: 1000947 NL

#### How it Works:

1. A VETUS "Splash-Stop" is directly connected to a Ø 50 mm VETUS deck plate. It ensures that overflowing diesel fuel and froth will not come out of the deck entry - soiling your deck and polluting the water - but will be neatly caught inside the reservoir (with a capacity of ca. 2 liters).
2. Excessive fuel will flow back into the main tank through connection. This connection also serves as the necessary tank ventilation.
3. The breather line to outside is to be installed to connection. A VETUS [Diesel No-smell filter](#) may be installed into this breather line as well. If the diesel-smell filter is positioned well above the deck level, the breather line may exit below the deck level, if so required.
4. Available with connection for Ø 1 1/2" or for Ø 2" fuel filling hose.



VT-FS3816(LIST \$102.00)\$98.80 1 1/2" DECK ENTRY 1-1/2" & 2"FILL & 5/8" VENT

VT-FS5116(LIST \$102.00)\$98.80 2" DECK ENTRY 1-1/2" & 2" FILL & 5/8" VENT

VT-FS5125(LIST \$102.00)\$98.80 2" DECK ENTRY 1-1/2" & 2" FILL & 1" VENT

[RETURN TO FUEL SPILL DEVICE MENU](#)

[RETURN TO MAIN MENU](#)